



### INSIDE VIEW OF STRUT

1. Mount GM W-Body Adapter to Lathe using Mounting Bolts (10 mm) and Hollow Adapters. Position Adapter as shown above.
2. Connect GM W-Body Adapter using Mounting Bolts (10 MM) and Hollow Adapters to the Caliper Mounting Tabs.

Adapter Part Number  
080-80000-82