

Adapter Application List

On-The-Car Brake Lathe

Printed by: RTI Technologies, Inc

MAKE	MODELS	ADAPTER
Audi	80-90-100	03
	A6 (1995) [Rear=03]	Hollow
	A8 (1995) [Rear=09]	13
	A8-V6 & V8 (1996) [Rear=Consult Factory]	13
BMW	Series 3 & 7	Hollow
Chevrolet	Camaro [Requires Off-set Tool Holders]	
	GEO Metro (1989)	Hollow
	Lumina Van	44
Chrysler/Dodge	Dodge Ram (1994) [Requires 100mm Clamp]	44
	Eagle Vision, Concorde, New Yorker, Intrepid	Hollow
	K-Series, Mini-Van, Caravan	60
	Intrepid [Bolts thread directly into Caliper Mtg. Holes]	Hollow
	Ram Truck-Diesel (1995) [Lathe mounting is critical due to very thick rotor]	44
	Dodge Dakota (1997)	48
Citreon	AX [11=Top & Hollow=Bottom]	11 & Hollow
	Visa 11 RE (1983), Xandio, ZX	09
	XM	Hollow
Daimler	All Models	Hollow
Fiat	127, 131, Uno	Hollow
	Cinguanto, Regato, [Requires 54mm Bolt]	Hollow
	Panda	05
	Ritmo	03

Ford/Mercury (USA)	2 Piston Caliper (1996), Capri (1991-94), Continental (1993-96), Contour (1995-96), Cougar (1992-96), Crown Victoria (1995-96), Escort (1991-96), Grand Marquis (1995-96), Mustang (1995-96), Mystique (1995-96), Probe (1989-96), Sable (1994-96), Taurus (1994-96), Thunderbird (1992-96), Town Car (1995-96), Tracer (1991-96), Windstar (1995-96)	Hollow
	Explorer 4x2 (1995-96) [Requires 100mm bolt]	Hollow
	Explorer 4x4 (1995-96), Festiva (1989-93), Lincoln Mark VIII [Requires 90mm Bolt]	Hollow
	Aerostar (1989-96), Bronco II (1989-96), Explorer 4x2 (1991-94), F150/F250 1 piston caliper (1989-95), F250/F350 2 piston caliper (1989-95), Ranger (1989-96)	Small Ford
	F350	Large Ford
	Aspire (1994-96), Continental (1989-92), Escort (1989-90), Lynx (1984-94), Sauble (1989-93), Taurus (1989-93), Tempo (1989-94), Topax (1989-94), Tracer (1989-90), Villager (1993-96)	48
	Cougar (1989-91), Crown Victoria (1989-94), Grand Marquis (1989-94), Lincoln Mark VII (1989-92), Mustang (1989-94), Thunderbird (1989-91), Town Car (1989-94)	62
	Falcon (Australia & New Zealand) [Consult Factory]	
Ford	Transit Van [Consult Factory]	Transit
(Europe)	Fiesta, Escort, Mondeo, Scorpio, Sierra, Granada	Hollow
GM	Century, Cutlas Ciera, Cutlas Cruiser, Caprice, Custom Cruiser, Road Master, DeVille, Fleetwood, Lumina Van, Ninety-Eight, Park Avenue, Brougham, Eldorado, Riviera, Toronado, Trofeo, Camaro, Firebird, Bonneville, Eighty-Eight, LeSabre, Cavalier, Sunbird, Seville, Beretta, Corsica, Achieva, Grand Am, Skylark, Transporter Van	44
	Monte Carlo, Cutlass Supreme, Grand Prix, Lumina, Regal [Rear=08]	W-Body
	Chevrolet S-10, GMC S-15, Camaro [Requires Off-set Tool Holders]	
	Chevrolet Vans (1986-95)	15
	GEO Metro (1989)	Hollow
Honda	All Models	Hollow
Hyundai	All Models	Hollow
Isuzu	All Models	Hollow
Jaguar	All Models	Hollow
Jeep	Grand Cherokee (1995)	Hollow

Mazda	323	48
	626 & 629 (1985-86), B2200 Pickup, RX7	Hollow
Mitsubishi	All Models	Hollow
	Canter Truck (Japan) [Requires Special Drive Adapter]	61
Nissan	200SX (1995), 300ZX , Altima (1993), Maxima (1995), NX1600 (1990-93), NX2000 (1990-93), Pathfinder (1990-96), SE V6 Truck, Sentra	Hollow
	Quest (1993)	48
Opel	Ascona, Commodore, Omega, Rekord	09
	Corsa	07
Peugeot	104, 304	15
	205, 205 GTI, 305, 309, 505, 604, 604 GTI	09
Porsche	911 Carrera (1995-96), 911 Turbo (1995-96) [Rear=Consult Factory]	09
	911 Carrera (1974-94), 928S, S4, GT, GT5 (1978-95), 944, 968 (1984-95)	
Rolls Royce	Front Only	15
Rover	All Models	Hollow
Saab	900	13
	9000	Hollow
Saturn	All Models	Hollow
Toyota	2WD-Compact, 2WD-T100, Cars-All Models	Hollow
	4WD-Compact, 4WD-Land Cruiser, 4WD-T100, 4WD-Tacoma	08
	Previa [Consult Factory]	
Vauxhall Carlton		09
Volvo	244, 264	11
	264, 740, 760	10
	480	Hollow
VW	Golf (1983-86), Passat, Polo, Santana	05
	Golf (1987)	Hollow

Demo Stands - Replacement Rotors:

GM Raybestos Part Number 5072 [Use Adapters 44]

Ford Raybestos Part Number 6082 [Use Adapters 48]

Form No. 560-80090-00