



MAHLE Clevite Inc., RTI Division
10 Innovation Drive
York, PA 17402 USA
Phone: 717-840-0678
Web-site: www.rtitech.com

Bulletin No: 562-80013-00
Issued: November 26, 2012

Subject:	Aborting Fill Cylinder Process
-----------------	--------------------------------

Model Numbers Affected:	All RHS980
Manufacture Dates:	All
Serial Numbers Affected:	All
Tools Required:	None
Parts Required:	None
Supplemental Document:	None
Action Required:	Allow system to fill to designated target or close valve on new fluid cylinder.

Stopping of the Fill Cylinder Process

During the fill cylinder process, **do not press** the STOP pushbutton to end the procedure. Allow the unit to fill to the target amount or close the valve on the new fluid cylinder to limit the quantity filled.

Pressing the STOP button could cause residual liquid refrigerant to remain in the accumulator which could lead to compressor damage.

The fill cylinder target amount can be adjusted in the SETUP procedure as found in the operation manual.